



### **Setting up your HP Officejet 470 Printer with Bluetooth**

1. Turn on your Pocket PC & your printer (be sure to have the bluetooth card inserted into the printer and that the blue light is on.)
2. On the main screen of the PDA (aka Today screen), locate the Bluetooth symbol and tap on it.
3. This will bring up the Wireless Manager screen. Tap on the Bluetooth box to turn it on.
4. Once it says 'On' and the blue light on the handheld is flashing, tap on Menu in the bottom right corner and then Bluetooth Settings.
5. Tap on 'Add new device'.
6. Once it finds the printer, highlight it and tap 'Next'.
7. The next screen will ask you to insert a passcode to setup a secure connection, we don't need to do this so we'll just tap 'Next'.
8. Another box will pop up asking if you want to add the printer to your device list, tap 'Yes'.
9. Next, you should see the printer in the list of devices. It could be under either Connected or Disconnected. Tap on the COM Ports tab at the bottom of the screen.
10. Tap on 'New Outgoing Port'.
11. Highlight the printer and then tap 'Next'.
12. Hit the dropdown list for Port and select 'COM1'.
13. Uncheck the box for Secure Connection and tap 'Finish' and then 'OK' in the top corner of your screen.

## How To: Set up your HP Deskjet 470

14. Another window may pop up asking if you want to enter a passcode, tap 'Cancel'.
15. Open Palm-Tech Inspector on your PDA, and open the inspection you want to print.
16. Go to File → Print (located at the bottom left of the screen).
17. The print screen will appear, locate the line that says 'Port'.
18. Click on the dropdown for 'Port' and select 'COM1'.
19. Then tap 'Start Printing'.
20. Bytes of information will transfer from the PDA to the printer and then a second print screen will appear. Customize the info as you see fit, press ok, and enjoy mobile printing!

If you have any other questions or if anything is unclear give us a call at 888-736-2462, or you can email at [support@pdmb.com](mailto:support@pdmb.com).